



Evektor SportStar Plus
 Check List Supplement to POH
 Refer to POH for complete descriptions

PREFLIGHT INSPECTION CHECKLIST

COCKPIT	
Clipboard	COMPLETE PAPERWORK
Documents	A.R.O.W. CHECK
Switches	ALL OFF
Brakes	CHECK POSITIONS
Master Switch	ON
Stall Warning	CHECK AUDIBILITY
Master Switch	OFF
Control Stick	FREE, CLEAR, CORRECT
Flaps	SET TO 50°

FLUIDS	
Fuel	CHECK LEVELS,
Oil Level	SUMP BOTH TANKS
Coolant	CHECK (burp first)
	CHECK LEVEL

NOSE	
Engine	CHECK CONDITION
Spinner	CHECK ATTACHMENT
Propeller	CHECK CONDITION
Air Intakes	CLEAR
Nose Gear	CHECK CONDITION,
	TIRE TREAD & INFLATION
Cowling	CHECK ATTACHMENTS
Tilting Canopy	CONDITION

LEFT WING	
Landing Gear	CHECK CONDITION
Tire	CHECK TREAD &
	INFLATION
Wheel Covers	CHECK CONDITION
Wing Surface	CHECK OVERALL
	CONDITION
Landing Light	CHECK CONDITION
Pilot Tube/Static	CHECK CONDITION OF
Ports	ALL PORTS
Wing Tip	CHECK SURFACE
	CONDITION
Position Lights/	CHECK CONDITION &
Beacons	ATTACHMENTS
Fuel Tank Vent	CHECK CLEAR
Aileron	CHECK CONDITION,
	ATTACHMENTS &
	MOVEMENT
Flap	CHECK CONDITION &
	ATTACHMENTS

FUSELAGE	
Antennas	CHECK CONDITION
Structure	CHECK OVERALL
	CONDITION

EMPENNAGE	
Tail Units	CHECK OVERALL CONDITION
Tail Skid	CHECK CONDITION
Rudder	CHECK CONDITION,
	ATTACHMENTS &
	MOVEMENT
Elevator	CHECK CONDITION,
	ATTACHMENTS &
	MOVEMENT
Trim Tab	CHECK CONDITION

RIGHT WING	
Flap	CHECK CONDITION &
	ATTACHMENTS
Aileron	CHECK CONDITION,
	ATTACHMENTS &
	MOVEMENT
Wing Tip	CHECK SURFACE CONDITION
Position Lights/	CHECK CONDITION &
Beacons	ATTACHMENTS
Fuel Tank Vent	CHECK CLEAR
Wing Surface	CHECK OVERALL CONDITION
Landing Gear	CHECK CONDITION
Tire	CHECK TREAD & INFLATION
Wheel Covers	CHECK CONDITION

Please return this checklist to aircraft after completion of inspection.