



PREFLIGHT INSPECTION CHECKLIST

COCKPIT
Documents
Switches
Ignition key
Battery Switch
Fuel
Strobes
Stall Warning
Battery Switch
Clipboard
Control Stick
Flaps
Canopy
A.R.O.W. CHECK
ALL OFF
OFF & OUT
ON
CHECK QUANTITY
ON, CHECK, OFF
CHECK AUDIBILITY
OFF
COMPLETE PAPERWORK
FREE, CLEAR, CORRECT
SET TO 40°
CLOSED (use handle)

NOSE
CHECK LEVEL,
SUMP TANK
CHECK (burp first)
CHECK CONDITION
CHECK ATTACHMENT
CHECK CONDITION
CLEAR
CHECK CONDITION,
TIRE TREAD & INFLATION
CHECK UNDERSIDE
CHECK ATTACHMENTS
CHECK LEVEL
CHECK ATTACHMENTS &
CONDITION
Fuel
Oil Level
Engine
Spinner
Propeller
Air Intakes
Nose Gear
Nose Wheel Pant
Cowling
Coolant, Brakes
Canopy

LEFT WING
Landing Gear
Tire
Wheel Covers
Wing Surface
Pilot/Static
Wing Tip
Position Lights/ Beacons
Aileron
Flap
CHECK CONDITION
CHECK TREAD &
INFLATION
CHECK CONDITION
CHECK OVERALL
CONDITION
CHECK PORTS CLEAR
CHECK SURFACE
CONDITION
CHECK CONDITION &
ATTACHMENTS
CHECK CONDITION,
ATTACHMENTS &
MOVEMENT
CHECK CONDITION &
ATTACHMENTS

FUSELAGE
Antennas
Structure
CHECK CONDITION
CHECK OVERALL
CONDITION

EMPELLAGE
Tail Unit
Tail Skid
Rudder
Elevator
Trim Tab
CHECK OVERALL CONDITION
CHECK CONDITION
CHECK CONDITION,
ATTACHMENTS &
MOVEMENT
CHECK CONDITION,
ATTACHMENTS &
MOVEMENT
CHECK CONDITION

RIGHT WING
Flap
Aileron
Wing Tip
Position Lights/ Beacons
Wing Surface
Landing Gear
Tire
Wheel Covers
CHECK CONDITION &
ATTACHMENTS
CHECK CONDITION,
ATTACHMENT & MOVEMENT
CHECK SURFACE CONDITION
CHECK CONDITION &
ATTACHMENTS
CHECK OVERALL CONDITION
CHECK CONDITION
CHECK TREAD & INFLATION
CHECK CONDITION

Preflight Inspection

Please return this checklist to aircraft after completion of inspection.